

# HDMI Switch - 5 Port (inputs)



www.hdmi-led.co.za www.hdmi-led.com

**Description:** An **HDMI Switch** will select one input from a multiple of connected HDMI Source Devices and route it to a single output. The output is connected to your television e.g. HDMI IN 1 on your TV. The number of Switch inputs are model dependent and range from 3 to 5.

**Purpose:** If your current television does NOT have sufficient HDMI inputs for the numbers of sources you wish to connect to it. Connecting and removing HDMI cables is NOT recommended and can lead to connector failure and are expensive to fix.

**Example:** if you only have 1x HDMI input available on your television but would like to connect up to 5x sources. Connect all the sources HDMI outputs to the inputs of a the switch. Connect the switch single HDMI output to the available HDMI input on your television. Select the desired HDMI sources to display via the switch remote control or manually via the SELECTED button.

DSTV / Satellite Decoders



Blu-ray / DVD Players



Laptop/ Desktop PC's



Video game Consoles



Media Players / TV Box etc.



5x HDMI



1x HDMI



TV / Monitor / Projector

Can be Full or Ultra HD




Device Supports:-



Other HDMI Switches in our Range

Part number:	Inputs	Output	Resolution	Shell	Power Supply
HSW-5x1PR-FH	5	1	Full HD (1920 x 1200)	Plastic	None
HSW-5x1MR-FH	5	1	Full HD (1920 x 1200)	Metal	5VDC
HSW-5x1PR-4K	5	1	Ultra HD (3820x 2160)	Plastic	None
HSW-5x1MR-4K	5	1	Ultra HD (3820x 2160)	Metal	5VDC



# HDMI Switch - 5 Port (inputs)



[www.hdmi-led.co.za](http://www.hdmi-led.co.za) [www.hdmi-led.com](http://www.hdmi-led.com)

**Description:** An **HDMI Switch** will select one input from a multiple of connected HDMI Source Devices and route it to a single output. The output is connected to your television e.g. HDMI IN 1 on your TV. The number of Switch inputs are model dependent and range from 3 to 5.

**Purpose:** If your current television does NOT have sufficient HDMI inputs for the numbers of sources you wish to connect to it. Connecting and removing HDMI cables is NOT recommended and can lead to connector failure and are expensive to fix.

**Example:** if you only have 1x HDMI input available on your television but would like to connect up to 5x sources. Connect all the sources HDMI outputs to the inputs of a the switch. Connect the switch single HDMI output to the available HDMI input on your television. Select the desired HDMI sources to display via the switch remote control or manually via the SELECTED button.

DSTV / Satellite Decoders



Blu-ray / DVD Players



Laptop/ Desktop PC's



Video game Consoles



Media Players / TV Box etc.



5x HDMI



1x HDMI



TV / Monitor / Projector

Can be Full or Ultra HD



Device Supports:-



Other HDMI Switches in our Range

Part number:	Inputs	Output	Resolution	Shell	Power Supply
HSW-5x1PR-FH	5	1	Full HD (1920 x 1200)	Plastic	None
HSW-5x1MR-FH	5	1	Full HD (1920 x 1200)	Metal	5VDC
HSW-5x1PR-4K	5	1	Ultra HD (3820x 2160)	Plastic	None
HSW-5x1MR-4K	5	1	Ultra HD (3820x 2160)	Metal	5VDC